


MODULAR OUTDOOR KITCHEN

BBQ1100034 BBQ KITCHEN

REFRIGERATOR MODULE (for small refrigerator)
BBQ1100070 BBQ kitchen

REFRIGERATOR MODULE (for large refrigerator)





MADE IN

GERMANY

PREMIUM







TABLE OF CONTENTS

7
<u></u>

IJ

KEY POINTS FOR ASSEMBLY	3
FOR YOUR SAFETY	3
CARE AND MAINTENANCE	3
IMPORTANT FOR THE FOUNDATION	3
DESCRIPTION OF SYMBOLS	3
SCOPE OF DELIVERY	4
ASSEMBLY - BBQ1100034	5
ASSEMBLY - BBQ1100070	6



KEY POINTS FOR ASSEMBLY

These assembly instructions show the assembly of the outdoor barbecue kitchen. Read these assembly instructions carefully before commissioning! Failure to observe the risks, warnings and safety precautions set out in these assembly instructions may result in injuries or property damage.

Observe a working temperature of +5 °C to +35 °C for assembly.

FOR YOUR SAFETY



DANGER! Danger of death and physical injury owing to improper use.

• Observe the Weber barbecue manual!



ATTENTION! Risk of cutting on sharp edges.

Install a keder strip on sharp edges



ATTENTION! Damage to the base module with drawers owing to tipping.

The base module with drawers may only be used in combination with a barbecue attachment or other base modules with doors or corner element. Anchoring to the wall using a wall mounting element is also permissible.



ATTENTION! Damage to the modules

 First assemble all base modules and connect all base modules together before installing drawers, insert compartments, doors, etc.



ATTENTION! Damage to the outdoor barbecue kitchen owing to high temperatures.

- The wall mounting element is a technical component which is not suitable for attachment to heat-sensitive materials.
- Do not place the wall mounting element on insulated or plastered walls.
 Have the façade or structure approved for attachment of the outdoor barbecue kitchen in advance by the manufacturer.
- Appropriate thermal separation between the outdoor barbecue kitchen and the façade or structure must be ensured on site (excluded from the product liability!).
- A temperature of up to 180 °C should be anticipated for wall mounting elements. Please note that the radiant heat from barbecues can still be up to 150 degrees 25 cm away.

CARE AND MAINTENANCE



ATTENTION! Damage to the outdoor barbecue kitchen owing to storm winds.

- Position the outdoor barbecue kitchen in an area which is sheltered from the wind.
- Do not store aggressive chemicals such as chlorine or de-icing salt in the outdoor barbecue kitchen.
- Remove sunscreen and other creams with water and soap.
- Do not use abrasive cleaning agents.
- The surfaces of the outdoor kitchen may become scratched. Protect the surfaces with liner and/or nonslip mats.

IMPORTANT FOR THE FOUNDATION

Prevent rising soil moisture and condensation by means of a thick plastic sheet under the foundation. Pay attention to rainwater in the foundation design.

Place the outdoor barbecue kitchen on a paved area.

DESCRIPTION OF SYMBOLS



USE WORK GLOVES DURING ASSEMBLY!



USE A SUITABLE UNDERLAY TO PREVENT SCRATCHES!



YOU WILL NEED A HELPER FOR THIS ASSEMBLY STEP.



TOOLS REQUIRED FOR THIS ASSEMBLY STEP.



NOTE/INFORMATION




SPIRIT LEVEL SYMBOL
Align the part in question using the spirit level.

H

Z

H K

SCOPE OF DELIVERY BBQ1100034 excl. refrigerator



1	BBQ2000157 side panel for refrigerator
2	BBQ2000170 bottom stop, refrigerator
	BBQ1102400A accessory set


BBQ1000101S base module incl. screw set BBQ1000700 closed panel

BBQ1001000S stainless steel closed cover incl. screw set

BBQ1102400S refrigerator installation kit incl. screw set comprising:

BBQ2000198 refrigerator installation kit components BBQ1102400a refrigerator installation kit accessory set





1	BBQ2002586 top reinforcement panel – large refrigerator (optional)
2	BBQ2002597 base cover
3	BBQ1000600 ventilated back panel (with cable gland)

BBQ1000101S base module incl. screw set BBQ1001000S stainless steel closed cover incl. screw set

ASSEMBLY - BBQ1100034


ACCESSORIES - BBQ1102400A:

10 pcs. truss head screws M4x10 DIN 7380-1 A2 Tx 20







Remove the bottom 4 truss head screws from the back panel.





Attach the base plate to the back panel with 4 truss head screws.



Attach the left + right side panels to the inside with 3 truss head screws each.









Align the refrigerator using the spirit level.

















DONE



ASSEMBLY - BBQ1100070









Tx20 SW8

Remove the front panel from the base module (4 truss head screws).



Attach the top reinforcement panel with 4 M4 1b stainless steel nuts for Dekton countertops.





1 Lift the refrigerator into the base module.

3 Insert the bottom ventilation plate.




ш


FR

က


C2



4 Push the plate out from the left and right through a slot in the base cover.



5 DONE





THE MODULAR OUTDOOR KITCHEN PERFECT FOR EVERY TERRACE. CREATED IN AUSTRIA - MADE IN GERMANY

OFFICE@BBQ-KITCHEN.COM (+43) 7243 23 596



BBQ KITCHEN GMBH MERKURSTRASSE 11 4614 MARCHTRENK | AUSTRIA

WWW.BBQ-KITCHEN.COM